

Cubiscan[®] N9



Operations Manual

Version 1.0

Quantronix, Inc.
Cubing and Weighing Systems

380 South 200 West
P.O. Box 929
Farmington, Utah 84025
U. S. A.

Phone: (801) 451-7000

Fax: (801) 451-0502

Web Site: <http://www.Cubiscan.com>

Cubiscan N9 Operations Manual

Cubiscan® and the Quantronix logo are registered trademarks of Quantronix, Inc.

Scanning New Dimensions™, Qbit™, QbitWIN™, and The FreightWeigh System™ are trademarks of Quantronix, Inc.

Windows® is a registered trademark of Microsoft Corporation.

Cubiscan® software and firmware are protected by international and domestic copyrights.

Cubiscan® 150 measurement products are protected by one or more of U.S. Patents Re42,430 and D490,328 and

foreign patents.

Cubiscan® 110 measurement products are protected by one or more of U.S. Patent Re42,430 and foreign patents.

Cubiscan® 125 measurement products are the subject of U.S. Patent 8,928,896. Another U.S. patent is pending.

Cubiscan® 225 measurement products are the subject of a pending U.S. patent application.

This document and website Copyright©2015 by Quantronix, Inc. All rights reserved.



Limited Warranty Quantronix New Product

Statement of Warranty. Quantronix, Inc.'s, warranty obligations are limited to the terms set forth below: Quantronix (hereinafter referred to as the "Seller") warrants that its new product is in accordance with Seller's published specifications (or those agreed upon with Buyer in writing) at the time of sale or lease and that it is free from defects in materials and workmanship under normal use for a period of one (1) year from the date of sale or the commencement date under a written equipment lease or rental agreement (the "Warranty Period"). If a hardware defect arises and a valid claim is received within the Warranty Period, at its option, Seller will either (i) repair the hardware defect at no charge, using new or refurbished replacement parts, or (ii) exchange the product with a product that is new or which has been manufactured from new or serviceable used parts and is at least functionally equivalent to the original product, or (iii) refund the purchase price of the product. For purposes of this warranty agreement, "Buyer" shall mean and refer to (i) the party which originally – whether from Seller directly, or from a distributor, agent or reseller authorized by Seller – purchases, or leases under a written equipment lease or rental agreement, the Seller's product which is the subject of this warranty, or (ii) any subsequent purchaser or transferee that acquires valid title to the equipment within the Warranty Period.

In the event of the occurrence of a claim under this warranty, the Buyer shall have thirty (30) days to notify Seller in writing of the nature and specifics of the claimed defect; provided, however, that any and all claims must be received before the expiration of the Warranty Period. Failure to notify Seller within such time period shall void this warranty. Any claim of a warranted defect is subject to inspection and analysis by Seller to conclusively identify or confirm the nature and cause of failure and application of this warranty.

This is a factory warranty and any defective components, mechanical or electrical, will be repaired or replaced, at the discretion and authorization of Seller, at Seller's facilities in Utah. It shall be the Buyer's

responsibility to return the faulty equipment or components to Seller at Buyer's expense. Seller's obligation shall not include transportation charges, nor labor, material, or service charges involved in the removal, return or installation of equipment or components. Seller reserves the right to incorporate improvements in material and design of its products without notice and is not obligated to incorporate the same improvements in equipment previously manufactured.

Exclusions and Limitations. This limited one (1) year warranty is applicable exclusively to original equipment products and components that were manufactured by Seller. Seller also warrants its replacement parts, subject to the terms and conditions set forth herein, for the lesser period of ninety (90) days from the date of delivery or until the expiration of the original warranty, whichever is greater. Seller does not warrant, for any purpose, any external accessories, including but not limited to computers, controllers and/or barcode scanners, that are manufactured by another manufacturer and sold under a separate label, even if they are packaged or sold with Seller's product. Seller's obligation and liability under this warranty is expressly limited to repair or replacement (at its option) of the warranted equipment or components within the Warranty Period. A purchase by Buyer of equipment that it had first leased or rented shall not start a new Warranty Period. Seller does not warrant that the operation of the product will be uninterrupted or error-free.

This warranty shall not apply to equipment or components which has/have:

Been the subject of repairs or modifications not authorized by Seller.

Been used with incompatible products.

Been operated under abnormal conditions or in an unintended manner.

Not been operated or maintained in accordance with Seller's instructions.

Been subject to misuse or abuse, negligent handling, improper installation, accident, damage by fire, flood, water or other liquid damage, abnormal electrical condition and/or power surge, earthquake, or other act of God.

Had serial numbers altered, defaced or removed.

 Been operated beyond capacity.

TO THE EXTENT PERMITTED BY LAW, THIS WARRANTY AND THE REMEDIES SET FORTH ABOVE ARE EXCLUSIVE AND IN LIEU OF ALL OTHER WARRANTIES, REMEDIES AND CONDITIONS, WHETHER ORAL OR WRITTEN, STATUTORY, EXPRESS OR IMPLIED. AS PERMITTED BY APPLICABLE LAW, SELLER SPECIFICALLY DISCLAIMS ANY AND ALL STATUTORY OR IMPLIED WARRANTIES, INCLUDING, WITHOUT LIMITATION, WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND WARRANTIES AGAINST HIDDEN OR LATENT DEFECTS. IF SELLER CANNOT LAWFULLY DISCLAIM STATUTORY OR IMPLIED WARRANTIES THEN TO THE EXTENT PERMITTED BY LAW, ALL SUCH WARRANTIES SHALL BE LIMITED IN DURATION TO THE DURATION OF THIS EXPRESS WARRANTY AND TO REPAIR OR REPLACEMENT SERVICE AS DETERMINED BY SELLER IN ITS SOLE DISCRETION. This statement sets forth the full extent of Seller's liability for breach of any warranty or deficiency in connection with the sale or use of the product. No employee, representative or reseller of Seller is authorized to change this warranty in any way or grant any other warranty.

EXCEPT AS PROVIDED IN THIS WARRANTY AND TO THE EXTENT PERMITTED BY LAW, SELLER IS NOT RESPONSIBLE FOR DIRECT, INDIRECT, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES RESULTING FROM ANY BREACH OF WARRANTY OR CONDITION, OR UNDER ANY OTHER LEGAL THEORY, INCLUDING BUT NOT LIMITED TO LOSS OF USE; LOSS OF REVENUE; LOSS OF ACTUAL OR ANTICIPATED PROFITS (INCLUDING LOSS OF PROFITS ON CONTRACTS); LOSS OF THE USE OF MONEY; LOSS OF ANTICIPATED SAVINGS; LOSS OF BUSINESS; LOSS OF OPPORTUNITY; LOSS OF GOODWILL; LOSS OF REPUTATION; LOSS OF, DAMAGE TO OR CORRUPTION OF DATA; OR ANY INDIRECT OR CONSEQUENTIAL LOSS OR DAMAGE HOWSOEVER CAUSED INCLUDING THE REPLACEMENT OF EQUIPMENT AND PROPERTY, AND ANY COSTS OF RECOVERING, PROGRAMMING, OR REPRODUCING ANY PROGRAM OR DATA STORED OR USED WITH SELLER PRODUCTS.

CONSUMER PROTECTION LAWS. FOR CONSUMERS WHO ARE COVERED BY CONSUMER PROTECTION LAWS OR REGULATIONS IN THEIR COUNTRY OF PURCHASE OR, IF DIFFERENT, THEIR COUNTRY OF RESIDENCE, THE BENEFITS CONFERRED BY THIS WARRANTY ARE IN ADDITION TO ALL RIGHTS AND REMEDIES CONVEYED BY SUCH CONSUMER PROTECTION LAWS AND REGULATIONS.

Some countries, states and provinces do not allow the exclusion or limitation of incidental or consequential damages or exclusions or limitations on the duration of implied warranties or conditions, so the above limitations or exclusions may not apply to you. This warranty gives you specific legal rights, and you may also have other rights that vary by country, state or province.

Manual updated January 16, 2026.

Table of Contents

Chapter 1	Product Description	
	Specifications	2
Chapter 2	Getting Started	
	The Measuring Area	4
	Powering the Cubiscan N9 On/Off	5
	Connecting to the Cubiscan N9	5
	Cubiscan N9 Home Screen	6
Chapter 3	Operation	
	Measuring Freight with Barcode Trigger	9
Chapter 4	Configuration	
	Settings	11
	Measure Settings	12
	Units	13
	Connection	14
	MQTT Settings	15
	Ethernet Settings	15
	Post Settings	16
	Scale	16
	Custom Scale Connection	17
	Parse Settings	18
	Cameras	19
	Image Settings	20
	Barcode	21
Chapter 5	Maintenance	
	Touchscreen Care	23
	Cleaning the Cubiscan N9 Lasers	23
	Change the Control Box Filters	23

Chapter 6

Troubleshooting

Cubiscan N9 Is Not Responding	26
Version	27
Software	27
Version	27
Power	28
Measurement error	28
Diagnostic	28
Diagnostics Log	29
Configuration Log	30
Calibration Log	31
Update Log	32

LIST OF FIGURES

Cubiscan N9	2
Measurement Area	4
On/Off Knob	5
N9 executable file	6
Home Screen	7
Measurement in progress	10
Measurement Results	10
Settings	11
Save Transfer Data	12
Measure settings	13
Units	14
Connection	15
Scale settings	16
Custom scale connection	17
Custom scale connection	18
Camera settings	19
Update camera	20
Image settings	21
Barcode settings	22
Control Box Front Filter	24
Control box side filter	25
Control Box Filter	25

Power switch	26
Version	27
Menu: Diagnostic	29
Logs	29
Diagnostic log	30
Configuration log	31

CHAPTER 1

PRODUCT DESCRIPTION

The Cubiscan N9 is a space-saving, static dimension scanning device that measures multi-piece, palletized, or non-palletized freight. The Cubiscan N9 can work with a heavy-capacity floor scale or in a stand alone capacity. Its overhead-mounted sensor configuration provides a comprehensive view of the freight measurement area in compact format.

The Cubiscan N9 is commonly used to dimension freight, for packaging planning, calculating transportation shipping charges, and storage space optimization. It may be customized to user needs. Barcode scanning and printing devices can be used with the Cubiscan N9 to create a versatile measurement system.

Freight is measured using Class 1 infrared laser sensing technology. Two laser scanners are mounted parallel to each other over the freight measurement area. Capacity for freight can be measured up to 8 x 8 x 8 feet. An optional floor or wall-mounted touchscreen display allows for a simple user operation process.

The Cubiscan N9 uses powerful sensing technologies to create a flexible and economical solution for today's most demanding dimensioning applications.




Figure 1
Cubiscan N9

Specifications

Power Requirements

200-250 V 16 A

Environmental

Operating Temperature: 32° to 104° F (0° to 40° C)

Humidity: 0 to 85% non-condensing

Measuring Sensor

Two infrared laser scanners, 905 nm, Class 1, (eye-safe), according to DIN EN 60825-1

Measurement Capacities

Measurement Range

Length: 1 in to 98.4 in (2.5 to 250 cm)

Width: 1 in to 98.4 in (2.5 to 250 cm)

Height: 1 in to 98.4 in (2.5 to 250 cm)

Measurement Increment: 1 in (2.5 cm)

Measurement Time: < 2.5 seconds

Physical

Length: 170 in (431 cm)

Width: 24 in (61 cm)

Height: 20 in (51 cm)

Suspended weight: 425 lb (193 kg)

Recommended ceiling height: 192 in (488 cm)

User Interface

Touchscreen (optional), mounted display.

Chapter 2

Getting Started

This chapter provides instructions for proper measurement, powering the Cubiscan N9 on and off, and connecting to the software interface using a computer. It also describes the different windows and functions that are found on the home screen.

The Measuring Area

It is recommended that you paint or tape lines on the floor to designate the measurement area, as shown in the figure below.



Figure 2
Measurement Area

Keep the measuring area free of debris that may affect the dimensioning of product. When dimensioning product, do not enter the measuring area until the measurement is complete.

If there is concern that product is not measuring correctly, please contact **Cubiscan Support** at 801.451.0500 for assistance.

Powering the Cubiscan N9 On/Off

Before powering the system on or off, ensure that the measuring area is clear.

To turn the Cubiscan N9 on, locate the red knob located on the control box, see Figure 3. Turn the red knob clockwise into the ON position.



Figure 3
On/Off Knob

Once the system has been powered on, the measure screen will appear on the display mounted to the Cubiscan. The Cubiscan N9 is ready to measure.

Connecting to the Cubiscan N9

The Cubiscan N9 may be accessed by a computer through an ethernet connection. Through the operating system, the Cubiscan N9 may be configured and calibrations may be performed. A user may perform other operations such as updating the system software or reviewing logs for diagnostic purposes.

To access the Cubiscan N9 with a computer, enter the IP Address of the system in a browser window. The operating system desktop will display.

To run the Cubiscan N9 software, open the **N9.exe** file within the

root folder (typically C:\Cubiscan\n9).




Figure 4
N9 executable file

The Cubiscan N9 software will launch and the home screen will appear.

Cubiscan N9 Home Screen

This chapter describes the different areas and windows found on the

home screen.




Figure 5
Home Screen

- Version** The Version screen displays general information about the system related to software version. For more information on the Version options, see "Version" on page 27.
- Settings** The Settings screen provides general options for configuring the system software and machine identification such as language selection. For more information on Setting options, see "Settings" on page 11.
- Measure Settings** The Measure Settings screen provides options for configuring triggers for measuring and how units will be displayed. For more information on configuring Measure Settings, see "Measure Settings" on page 12.
- Connection** The Connection screen provides options for configuring the connection to the Cubiscan N9 and the transfer of data. This includes Ethernet and Post settings. For more information on setting up connections to the Cubiscan N9 and other connection related options, see "Connection" on page 14.
- Scale** The Scale screen provides options for connecting a scale to the Cubiscan N9. Pre-configured options are provided along with the ability to enter custom settings. For more information on connecting and configuring a scale for the Cubiscan N9, see "Scale" on

page 16.

- Cameras** The Cameras screen provides options for connecting various rgb cameras to the Cubiscan N9 for capturing product images. Among the options are settings for how images will be captured and transferred. For more information on connecting cameras on the Cubiscan N9 and other image options, see “Cameras” on page 19.
- Barcode** The Barcode screen provides options for connecting barcode scanners to the Cubiscan N9. Options are available to parse data and to provide modes for validating barcode information. For more information on connecting barcode scanners and configuring barcode features, see “Barcode” on page 21.
- Calibration** The Calibration screen provides operations for performing a calibration of the Cubiscan N9. At this time, all calibrations are done at install by trained technicians. If a recalibration is needed, please contact **Cubiscan Support** at **801.451.0500** for assistance.
- Diagnostics** The Diagnostic screen provides logs for troubleshooting issues and tracking software changes and updates. For more information on diagnostic logs available and how to access them, see “Diagnostic” on page 28.

Chapter 3

Operation

This chapter provides instructions for operating the Cubiscan N9.

Measuring Freight with Barcode Trigger

To configure the Cubiscan N9 to trigger with a barcode scan, first enable this option in setting, see “Measure Trigger” on page 13. Complete the following steps to measure freight with barcode trigger enabled:

1. Power on the Cubiscan N9. For information on how to do this, see “Powering the Cubiscan N9 On/Off” on page 5.
2. Make sure that the freight you want to measure is in the measurement area.
3. Scan or enter a barcode into the barcode field. With barcode trigger configured, scanning a barcode will automatically begin the measurement process.
4. A yellow light will appear on the measurement screen mounted to the Cubiscan N9, indicating that measurement is in process.

Do not move freight or move into the measurement area while the light is yellow as this will disrupt the measurement.




Figure 6
Measurement in progress

5. The Cubiscan N9 arm will move over the freight. This process usually takes about 15 seconds. Once the measurement is complete a green light will appear with a message indicating the measurement is complete. The dimensioned values will be displayed on the measurement screen.




Figure 7
Measurement Results

6. You can export the information by configuring the Cubiscan S9 to send data in the settings, see "Post Settings" on page 16.


Chapter 4

Configuration

This chapter provides instructions for using the Cubiscan N9 touchscreen to set up preferences and operate special features that the Cubiscan N9 offers.

Settings

The following options are settings that you can select to configure the Cubiscan N9 to your specifications.



The screenshot shows a dark-themed interface titled "GENERAL SETTINGS". It contains the following elements:

- Language:** A dropdown menu currently set to "English".
- Machine ID:** A text input field with "Machine ID" as a placeholder and a blue "SUBMIT" button to its right.
- Site ID:** A text input field with "Site ID" as a placeholder and a blue "SUBMIT" button to its right.
- Save Transfer Data:** A checkbox that is currently unchecked.
- Hide Measure Button:** A checkbox that is currently unchecked.

Figure 8
Settings

- | | |
|---------------------------|-----------------------------------------------------------------------------------------------------------------------------------|
| Language | Select your desired language form the following options: English, French, Spanish, Japanese, Korean, Chinese, and German. |
| Machine ID | Set the Machine ID for the unit by entering the ID into the text field and clicking [SUBMIT]. |
| Site ID | Set the Site ID for the unit by entering the ID into the text field and clicking [SUBMIT]. |
| Save Transfer Data | Click in the check box to enable the saving of transfer data during measurements. A field will appear below the setting to select |

location where the data will be saved. Click in this field to open a file browser to select where to save data.




Figure 9
Save Transfer Data

Hide Measure Button Click the check box to hide the measure button on the main screen. This may help where barcode is enabled to ensure that the scanning of the barcode initiates measurement.

Measure Settings

The following options can be set to configure the measurement

settings.




Figure 10
Measure settings

Measure Trigger Set the trigger for measurement. Options include: Manual Only or Barcode Filled.

Manual Only: Measurement only triggers when manually triggered.

Barcode Filled: Measurement is automatically triggered when barcode is scanned.

Send Data Trigger Set the trigger for sending data. Options include: **Dimensions, Weight, Barcode, and Data Filled.**

Dimensions: Data will be sent once dimensions are collected.

Weight: Data will be sent once weight is collected.

Barcode: Data will be sent once barcode is scanned.

Data Filled: Data will be sent once all data is collected.

Display Dimensional Weight Toggle to enable display of dimensional weight on home and view screen.

Display Freight Class Toggle to enable display of freight class on home and view screen.

Units

The Units section, provides configuration of measuring units. These

units will be displayed on the measurement screen and will be posted to data acquired during measurements.




Figure 11
Units

- Dim units** In this field you can select **inches**, **centimeters**, or **millimeters** for your dimensional units.
- Weight units** In this field you can select **pounds** or **kilograms** for your weight unit.
- Dim-factor** In this field you can select a **domestic** or **international** dim-factor.
- Factor** Will automatically set to the selected **Dim-Factor** (domestic or international). Below in the **IN LB**, the pre-configured factor will be displayed for the given units and dim-factor selected. This factor may be adjusted as needed by entering the desired factor in the text field.

Connection

The following options are settings that you can select to configure

the Cubiscan N9 to your specifications.

Figure 12
Connection

MQTT Settings

The MQTT is used to connect to the Cubiscan N9 from the controller. Although, the settings of the MQTT may be adjusted, they need to match the IP Address and port of the Cubiscan N9 to ensure connection.

MQTT IP Address Enter the IP address to connect to the Cubiscan N9. The address must match the IP of the system.

MQTT Port Set the port to connect to the Cubiscan N9. The port must match the port used by the system. In most cases, this should be port 1883.

Ethernet Settings

The Ethernet Settings field allows you to select the Ethernet settings for the Cubiscan. The following information is displayed to help you connect with the Cubiscan: **MAC Address, IP Address, Subnet, and Gateway.**

Connection Select the type of connection from the dropdown menu options.

Status: Enabled Toggling this option enables or disables the Cubiscan's ability to communicate via Ethernet.

Status: DHCP Check box to enable or disable a Dynamic Host Configuration Protocol (DHCP) connection.

Machine Port Enter the port number for the webserver.

Post Settings

Enable Post Toggle to enable/disable posting of measurement data.

Post URL Enter the address of the network to post data.

Post Port Enter the network port used to post data.

Post Auth. Choose the type of authorization key from dropdown. Options include: **Basic**, **Bearer**, or **Qbit**.


Basic: Server uses a simple username password combo to validate if data from the sender should be accepted.

Bearer: Server uses a token recognized by both server and sender to validate if data from the sender should be accepted.

Qbit: Like Bearer, server uses a token recognized by both server and sender to validate data. Used specifically to work with Qbit products.

Scale

The following options are settings that you can select to configure the scale for the Cubiscan.



SCALE

SCALE SETTINGS

Scale: B-TEK T403

Weigh Mode: Constant

CONNECTION

Ports: COM4 REFRESH

UPDATE SERIAL

Figure 13
Scale settings

Scale Select the appropriate scale from the dropdown or add a custom scale configuration if scale is not listed.

The following scales are pre-configured: FW-150, MyWeigh HD150, FB2250, Cardinal, MT IND-231, CAS PB-150, DWP-440, Veritas HL-318L, Ishida IWX-D or IGX, B-TEK T403, or USB HID.

To add a custom scale configuration, see “Custom Scale Connection” on page 17.

- Weigh Mode** Select the weigh mode from the dropdown menu. Select Constant for continued display of the weight. Select hold stable to display the weight once the a consistent weight is read on the scale.
- Connection: Ports** Select the communication port of the scale.

Custom Scale Connection

Generally only a port is needed to set up the scale. However, if the scale model is not found in the scale drop down list, a custom connection may be created.

To setup a custom connection, select Add Custom from the scale dropdown list and enter the information in the required text fields under Connection.




Figure 14
Custom scale connection

- Connection** Select the type of connection for the scale form the drop down. Options include: **USB HID**, **Serial**, or **Ethernet**.


- Ports** Select the port the scale will connect to form the drop down. If the

port does not show in the drop down, click **[REFRESH]**. If it still does not display in the drop down, check connections and refresh again.

- Baud Rate** Select the baud rate for the scale from the drop down. Options include: **1200, 2400, 4800, 9600, 19200, 57600, or 115200.**
- Parity** Select the parity of the scale form the drop down. Options include: **None, Odd, or Even.**
- Stop Bits** Select the number of stop bits used when transmitting data. Options from the drop down include: **One or Two.**
- Data Bits** Select the number of data bits in a data packet form the drop down. Options include: **Five, Six, Seven, or Eight.**

Parse Settings

The following settings are for setting up parsing of data transmitted from the scale.



PARSE
NOTE: To type control characters use the form "\x<ASCII CODE>". All positions are 0 indexed.

Request String:	Request
Start String:	Start
End String:	\r\n
Weight Start Pos:	1
Weight Data Size:	9
Unit Start Pos:	11
Unit Data Size:	2

Figure 15
Custom scale connection

- Request String** Enter the string to request string for requesting data from the custom scale.
- Start String** Enter the string to start the transmitting of data from the custom scale.
- End String** Enter the string to end the transmitting of data from the custom scale.
- Weight Start Post** Set the number of start position for data packet.

Weight Data Size Set the size of data transmitted from the scale.

Cameras

The following options are settings that can be selected to configure the cameras for the Cubiscan N9.

Figure 16
Camera settings

Camera Count Displays the number of rgb cameras used by the N9.

Current Camera Select the camera to configure from the camera count drop down.

View Camera Click in the box to enable or disable the camera view on the main screen.

Name Displays the assigned name of the camera selected from the camera count dropdown. Type in the text box to change the name of the camera.

IP Address Displays the IP Address of the camera selected from the camera count dropdown. Type in the text box to change the IP Address for accessing the camera.

Port Displays the Port of the camera selected from the camera count dropdown. Type in the text box to change the Port for accessing the


camera.

Profile Select the profile for the images captured by the camera. Options include: **h264** and **jpeg**.

Auth. Select the type of authentication used for accessing the camera. Options include **digest** or **none**.

**Username/
Password** Enter the username and password for accessing the camera.

When setting or updating settings for a selected camera, remember to click **[UPDATE CAMERA]** in order to keep the desired settings.



The screenshot shows a web interface titled 'CAMERAS' with a 'CAMERA SETTINGS' section. The settings are as follows:

Field	Value
Camera Count:	2
Current Camera:	1 - cam_1
View Camera:	<input checked="" type="checkbox"/>
Name:	cam_1
IP Address:	10.1.9.40
Port:	443
Profile:	profile_1 h264
Auth:	Digest
Username:	onvif
Password:	****

At the bottom of the settings form, there is a blue button labeled 'UPDATE CAMERA' which is highlighted with a red border.

Figure 17
Update camera

Image Settings

The following options can be set to configure image settings for

images captured by the Cubiscan N9.




Figure 18
Image settings

Capture Images on Measure	Click check box to toggle image capture during measurement.
Embed in JSON	Click check box to toggle the embedding of JSON with image file.
Font Size	Set the font size of the text rendered onto images captured after measurement. Allows for text to be reasonably sized when varying image resolutions.
Use Name	Click Check box to toggle the use of the camera name with images captured.
Use Timestamp	Click Check box to toggle the use of the timestamp with images captured.
Use Dimensions	Click Check box to toggle the use of the measured dimensions with images captured.
Use ID	Click Check box to toggle the use of the item ID with images captured.

Barcode

The following options are settings that you can select to configure

the barcode scanner for the Cubiscan.


The image shows a software configuration window titled "BARCODE". It contains four sections: "BARCODE SETTINGS" with a "Count" dropdown set to "1"; "CONNECTION" with a "Connection:" dropdown set to "USB HID"; "PARSE" with a "Suffix:" text input field containing "v" and a blue "SUBMIT" button; and "VALIDATION" with a "Mode:" dropdown set to "None".

Figure 19
Barcode settings

- Count** Set the number of barcodes required to scan during measurement.
- Connection** Select the type of connection for the barcode scanner from the dropdown. Options include: **USB HID**, **Serial**, and **Ethernet**.
- Parse: Suffix** Enter the required suffix to parse at the end of the data packet. After entering the suffix, click **[SUBMIT]** to keep setting.
- Validation: Mode** Select the mode to restrict which barcodes are included in the final measurement. Options include: **None**, **Exact**, and **Min Max**.
- None:** No restriction is placed on the barcode.
- Exact:** Select for a set number of characters in the barcode.
- Min Max:** set a range of characters in the barcode. To set the range, enter the minimum and maximum number of characters.

Chapter 5

Maintenance

This chapter provides information on the care and maintenance of the Cubiscan N9. Routine maintenance and careful handling will help keep the Cubiscan N9 in good operating condition and prevent service call or repairs.

Touchscreen Care

To clean the touchscreen, moisten a soft cloth with water, then gently wipe the screen clean with the cloth, do not spray liquid directly on the touchscreen.

Do not let the touchscreen come into contact with any sharp objects.

Cleaning the Cubiscan N9 Lasers

The laser heads should be kept clean. While some dust normally won't interfere with sensor operation, they should be cleaned routinely to prevent the possibility of interference. The frequency with which the laser heads should be cleaned depends on the Cubiscan N9's operating environment.

To clean the laser heads, you will need the following.

- Ladder (or another means of reaching the Cubiscan N9 laser heads)
- Clean, dry microfiber cloth

Once the laser heads are within reach, gently wipe the laser head surfaces with a dry microfiber cloth.

When you clean the laser heads be sure that you are following all required safety regulations.

Change the Control Box Filters

This chapter provides information on how to change the control box

filters. These filters should be changed as needed, depending on the N9's operating conditions.

To change the filters, complete the following steps:

1. Locate the two filters located on the front and side of the control box (shown below).



Figure 20
Control Box Front Filter



Figure 21
Control box side filter

2. Gently wiggle the filter guards free. They should simply pop out.
3. Clean the filters or replace them with new ones.



Figure 22
Control Box Filter

4. Snap the filter guards back into place.

Chapter 6

Troubleshooting

This chapter provides assistance in identifying and solving common problems with the Cubiscan N9. If you encounter problems not covered in this chapter, or if a defect is suspected, contact your system integrator or call **Cubiscan Support** at **801.451.0500** for assistance.

Cubiscan N9 Is Not Responding

If the Cubiscan N9 is not responding, try powering it off. For information on how to do this, see “Powering the Cubiscan N9 On/Off” on page 5. Make sure that the power switch is turned off for 20 seconds or more to ensure that all power has been drained from the system.



Figure 23
Power switch

If powering the Cubiscan N9 off does not work, contact **Cubiscan Support** at **801.451.0500** for assistance.

Version

This section describes the Version menu of the Cubiscan N9. The Version menu contains useful information and records of the Cubiscan N9.

To access the version information, perform the following steps:

1. From the menu side panel, select **VERSION**.




Figure 24
Version

Serial Number This field displays the serial number of the Cubiscan.

Software

Operating System This field displays the operating system currently used on the system.

Version The model and firmware version of the Cubiscan is displayed at the top of the Version screen.

Checksum This field displays the checksum for the software.

Version

Software Update To update system software, select the update software Available Update drop down and tap **[Start Update]**.

Power

- | | |
|-----------------|----------------------------------------------------------------------------------------------|
| Reboot | Click [REBOOT] to restart the Cubiscan N9 and boot the software again. |
| Shutdown | Click [SHUTDOWN] to close the Cubiscan N9 software and shutdown the system. |
| Restart | Click [RESTART] to restart the Cubiscan N9 software without shutting down the system. |
| Close | Click [CLOSE] to close the Cubiscan N9 software without shutting down the system. |

Measurement error

If the Cubiscan N9 reports a measurement error, complete the following steps.

1. Ensure the measurement area is free from objects not being measured, including hands that may be captured during the measurement. It may be helpful to use a different display mode to identify any unwanted measurements.
2. In some case a recalibration may be needed to ensure the Cubiscan is measuring properly.
3. If problem persists, cycle the power and remeasure.

If you are still receiving a sensor error, contact **Cubiscan Support** at **801.451.0500** for assistance.

Diagnostic

The following options can be used for diagnostic purposes of your Cubiscan N9. Two types of logs exist with diagnostic information about the system: the diagnostic log and the configuration log. Use these logs to troubleshoot possible issues with the Cubiscan N9.

To access the diagnostic information, perform the following steps:

1. From the menu side panel, select **DIAGNOSTICS**.




Figure 25
Menu: Diagnostic

A list a logs will display on the screen: diagnostic log, configuration log, calibration log, and update log. Select the diagnostic information you wish to view by tapping the respective button.




Figure 26
Logs

Diagnostics Log

The diagnostics log displays system messages, including error

messages. Each entry is stamped with the date and time that it occurred.

To access the diagnostics log, tap **[DIAGNOSTICS LOG]** from the Diagnostics menu. The diagnostics log will display on the screen.




Figure 27
Diagnostic log

Configuration Log

The configuration log displays the configuration audit trail. When configuration changes are made to the Cubiscan N9, the changes are recorded here. Changing dimension units, weight units, and dim factors are examples of the changes that are stored here.

To access the configuration audit log, tap **[CONFIGURATION LOG]** from the Diagnostics menu. The configuration log will display on the

screen.




Figure 28
Configuration log

Calibration Log

The calibration log displays the results of calibration. When a calibration is performed on the Cubiscan N9, any errors are recorded here. If the calibration is successful, it will be logged as well.

To access the calibration log, tap **[CALIBRATION LOG]** from the Diagnostics menu. The calibration log will display on the screen.

Update Log

The update log displays a timestamp of the updates to the system software. The update log provides a list of each update to the Cubiscan N9 and when it was performed. This may be helpful to determine if a update is required.

To access the update log, tap **[UPDATE LOG]** from the Diagnostics menu. The update log will display on the screen.